



Hanging instruction for woven vinyl wallpaper

The instructions below cover most installation procedures. It will help you to realize a beautiful and durable wall decoration. Please read these instructions carefully before applying to a wall.

The installation of texlyweave® wallpaper must be performed by a professional hanger with experience in putting up heavy fabric wall covering.

1. Terms and conditions

The material must be examined before hanging.

Check each roll for visual defects before installing. Visible faults have been reported before cutting or installing. Any installation of material implies any quality acceptance. If the material is deemed defective, texlyweave® will replace it. The liability is limited to replacing defective material only and is not liable for the cost of removal or reinstallation.

The weave of the texlyweave® wall covering will not run parallel to the cut edge. Therefore, the product's wave, bow, or skew is expected due to how texlyweave® is woven. The tolerance for bow and skew is 1.5" in either direction.

Some patterns will also exhibit light and dark shading in the material, which is also expected. This shading is also evident at the seams, where two pieces of the same style may have a different shade.

The material should be tested by hanging at most three strips. Please don't hesitate to contact us if you have questions after turning in the first three strips. texlywaeve® will not be responsible for any labour costs after that.

2. Tools required

Tape Measure · Level · Steel Ruler or Straight Edge · Razor Knife · Pencil · Plastic Smoother

3. Prepare the wall

The temperature should preferably be between 18°C and 25°C.

Before installing your wallpaper, prepare the work area surface clean, smooth, and dry intact. Make sure electrical outlets are off and remove wall fixtures. For best results, clean and properly prepare all wall surfaces. Old wallcoverings and paste residue should be removed. Surface protrusions and low spots sanded and filled.

Next, prepare the surface with a premixed, universal wallpaper primer-sealer.

4. Pay attention to the back style of texlyweave® wallpaper

There are two types of texlyweave® wallpaper: woven vinyl with nonwoven lining and without lining.

If hanging texlyweave® woven vinyl wallpaper without a lining, ensure that the surface colour remains consistent throughout the installation unless you intentionally desire an exposed-bottom style effect with contrasting colours. Variations in wall colour can impact the final appearance of the woven vinyl after installation.

If hanging texlyweave® woven vinyl wallpaper with a lining, please do not reverse, and be aware that the inner lining is not removable.

Please do not press harshly against the surface when removing any bubbles or wrinkles. Too much force can cause the paste to bleed through the fabric since no liner is backed, resulting in possible permanent stains, especially for wallpaper without lining.

5. Recommended Adhesive

PSA – Pressure-sensitive adhesive



[Henkel Aquence LA 3141](#)

[Datasheet](#)



[Uzin KE2000 S](#)

[Datasheet](#)

Contact adhesive



[Henkel Thomsit K 188 E](#)

[Datasheet](#)



[Uzin WK222](#)

[Datasheet](#)

The adhesive should be pasted to the wall only. Test a small piece to determine the amount of glue to apply and how long the adhesive should be tacked up before putting the fabric up. Allow adhesive to become very tacky (about ten minutes, depending on site conditions); otherwise, the adhesive may seep through to the face. This is important for a successful installation.

6. Hanging

6.1 When ready to begin, measure the wall length and pre-cut strips to wall height; allow an extra 5 cm on the top ceiling and bottom baseboard for trimming. Make sure to align any design from strip to strip before cutting and hanging each strip.

Cut and trim the product with a sharp razor knife, changing the blade often to help maintain a smooth, clean cut. Number the back of each strip to keep your design in the correct order. Be sure to allow a pattern match, either random, straight across, or drop match.

Use a new razor blade to trim off 6-8 cm from the selvedge. (approx. Width of most straight edge)

6.2 Roll up the wallpaper with the pattern on the inside. Due to the fabric's heavyweight, long drops may require nail-tacking at the ceiling first.

6.3 Use a plumb line positioned 180 cm from the corner of the room due to the 200 cm width of the wallpaper. This is the guide for your 1st strip, and it needs to be a straightforward, vertical line. Carry the first strip to the wall with the correct adhesive, unroll and hang it.

Allow overlap between the ceiling and baseboard. Seams should be vertical; using a smoothing brush or plastic smoother, remove any air bubbles, and make sure all the wallpaper has made good contact with the wall without distorting or stretching the wallpaper.

Use a seam roller to lightly flatten seams. Trim with scissors or razor knives at the ceiling baseboards.

6.4 Please place the second strip at the edge of the first strip (or overlap and double cut) and smooth out. If double cutting, please take care to avoid scoring the wallboard underneath. The blade of the utility knife should be very sharp and regularly changed. The adjoining length shall be laid under the straight-cut edge so the overlap toll is about 2-3 cm. Next, align the two sizes so that the fill direction of the texlyweave® yarns is straight across the seam. The excess trimmed edge must be removed from the wall. Repeat the previous steps for each strip.

6.5 After three strips have been smoothed to the wall surface and excess paste removed, examine the installed wallpaper for uniformity in colour. Then, proceed in the same manner around the room.

Follow the steps above to keep going and finish hanging your strips.

6.6 Sponge each strip with clean water to remove any excess adhesive. Use a soft bristle brush to clean, if necessary. Change this wash water frequently. Blot this dry with a clean towel. Be sure to wash the ceiling and baseboards to remove any adhesive residue.

Important points:

Sharp objects can damage texlyweave® irreparably. Avoid this appropriate use of protection on the wall, and be sure not to use them to remove stains.

Ensure the wallpaper is always protected when hanging frames or wall decorations. Contact rubber materials should be avoided. Prolonged contact will stain texlyweave® irreparably. In such situations, the rubber is replaced with another plastic, or protection is applied.

Always use epoxy or comparable waterproof adhesives if texlyweave® wallpaper rolls are installed outdoors.

The Warranty For Complete Or Partly Compensation Of Complaints by Dragonshine Will Be Void If the Above Installation Instructions Are Not Strictly Respected.

Attention: Some white fibres may appear at the seams. These will spontaneously break off during use. texlyweave® is a polyester yarns core instead of fibreglass to avoid inhaling broken fibreglass into the lungs. A low temperature of about 70 hairdryer breezing could curl and seal the fibre.

texlyweave® woven vinyl wallpaper can be brushed or vacuumed. However, stubborn stains are best removed with a wet cloth.



we challenge the norms of weaving

Informed by continuous contact with designers and professionals in the textiles and interiors industry, we create, manufacture and distribute solutions to enhance new surface comfort of the spaces in which people live and work.

texlyweave® products are technically sophisticated, sensitive, and hard-wearing. Their hallmark is the textile in which they are from wall to floor: **texlyweave®** is woven in our workshop in China in a palette of hundred colors. Since 2002, it has been our pride and delight to play our part in developing quality furniture and interior in China, Asia, Europe, the US, and beyond.

our woven vinyl from wall to floor with an exclusive **texlyweave®** creation!

The above information is based on our experience and careful investigations. The variety of associated materials, constructions, and working conditions cannot be individually checked or influenced by us. So, your work's quality depends on your professional judgment and product usage. If in doubt, conduct a small test or obtain technical advice. Observe the installation recommendations of the related information and knowledge. The publication of this Product Data Sheet invalidates all previous product information.

We reserve the right to make changes within the scope of technological advancement without prior notice.

此处的资料是根据我们实际掌握的知识和经验而提供的，因使用不通的材料以及工作条件的改变草果了我们的控制范围，我们郑重建议进入深入细致的实验并与我们的工作人员协商，对于以上资料，我们不接受任何相关责任。

我司有权根据情况对以上内容进行修改。

更多資訊，謹請垂詢！

For more information, please contact us at
info@dragonshine.net!



FLIPHTML5

